

SUPERPRO[®]/2000

Operation Instructions for Stand-Alone Mode

Introduction

SUPERPRO/2000 comes with two work modes:

1. PC Hosted Mode (Remote Mode)
This is the standard mode universal programmers work under. Programmer is connected to PC via printer port and controlled by the software which integrates powerful functions for all engineering purpose.
2. Stand-Alone Mode:
Powered by MCU, LCD, large capacity FLASH memory for algorithms and user data, SUPERPRO/2000 performs same functions as under PC-hosted mode such as Program, Read, Blank Check, Verify, Erase, Secure and Buffer Edit. Data buffer are non-violated and algorithms are updateable via printer port.
Below is instructions for stand-alone mode only. Please refer to USER'S GUIDE- SUPERPRO FOR WINDOWS for PC-hosted mode.

Features

- Ultra-high programming speed. Program 8Mb FLASH Memory in 12 sec.. with SUPERPRO/2000+ and 20 sec. With SUPERPRO/2000.
- Embedded high-speed MCU, keypad, 16X2 LCD display, 4Mb algorithms memory, 4Mb non-violated data buffer(8Mb, 32Mb,128Mb optional)
- ZIF48 universal pin-drivers, universal adapters. Supports E/EPROM, FLASH, Microcontroller, PLD. Tests standard logic devices and SRAM.
- Algorithms updateable via printer port. ■ Supports low voltage devices down to 1.8V.
- Pin integrity and insertion check before program ■ Automatic electronic serial number generation and insertion.
- Full-auto mode enable zero-key-stroke operation. Programming starts upon detection of correct insertion of chips.
- User-editable batch command.
- Standard functions including Program, Read, Blank Check Check, Verify, Erase, Secure.
- Buffer Edit, Buffer Checksum.

Menu

Keypad

ENTER	Select and enter submenu
EXIT	Exit to upper menu.
↑, ↓	Scroll to select. Change data at cursor location when editing buffer.
→, ←	Scroll to locate address or data in buffer editing.

RUN

Perform real action to chips. Type of chip should be selected before action.

Function set varies with types. Standard functions are as follows:

AUTO	Execute the command sequence t user defined in SETTING-EDIT AUTO
PROGRAM	Programs chip with buffer data.
READ	Read chips and save data to buffer (FLASH) , Calculate and save checksum of the data file for verify of next power-up.
BLANK CHECK	
VERIFY	
ERASE	
SECURE	Program lock bit of chips.

SELECT DEVICE

Select devices to be handled. Use ENTER and ↑ or ↓ to select, first select manufacture and then type..

Your select will be saved automatically as default device , no selection is need when enter next time.

Operation will be rejected and warning will be given if the capacity of the device selected is larger than that of the flash memory. Please contact your local dealer for upgrade of flash memory.

BUFFER

BUFFER EDIT

View or modify buffer. Valid only for memory and microcontroller.

ENTER and then will be displayed the first address and data. Use → or ← to move cursor to digit to be viewed or changed. Use ↑ or ↓ to change the number and so change the address or data.

CHECK SUM

Calculate the checksum of buffer and compare with the value saved last time. This is important to avoid loss in volume product due to accident violation of data.

SETTING

EDIT AUTO

Define command sequence which can be executed by enter AUTO in RUN .

CHIP ADDRESS

ENTER and use ↑ or ↓ to set chip start address. Enter and then set chip end address. Default value in the library will be used upon selection of chip type.

BUFFER ADDRESS

ENTER and use ↑ or ↓ to set buffer start address. Enter and then set buffer end address. Default value in the library will be used upon selection of chip type.

AUTO CHECKSUM

ENTER and use ↑ or ↓ to toggle **ENABLE** and **DISABLE** .

If **ENABLE**, Checksum will be calculated automatically after **READ**.



INSERTION CHECK

ENTER and use ↑ or ↓ to toggle **ENABLE** and **DISABLE**.

If **ENABLE**, programmer will automatically check if the chip is inserted properly before program. You can select **IGNORE** or **EXIT**.

BEEPER

ENABLE or **DISABLE** the beeper.

AUTO COUNTER

ENTER and then use ↑ or ↓ to toggle **ENABLE** and **DISABLE**.

As soon as **ENABLE** is selected, programmer will ask you to enter in the address to save the counter value and the initial value. The counter will step up by one and write the current value to the address specified in the chip automatically after each successful program. secure the chip after program.

AUTO RUN

ENTER and then use ↑ or ↓ to toggle **ENABLE** and **DISABLE**.

If **ENABLE**, programmer will monitor socket continually and start programming automatically upon detection of chip insertion.

ENCRYPTION

ENTER and then use ↑ or ↓ to edit encryption table (exist in only some microcontrollers).

Update of embedded algorithms library

1. Connect programmer to PC printer port. Turn on power and run SUPERPRO For Windows.
2. Enter **LIBRARY**. **LIBRARY-READ** read in current library in programmer algorithm memory and modify. **LIBRARY-MODIFY** load library saved on harddisk to modify.
3. **REMOVE** unwanted devices. Use **SEARCH** or **MANUFACTURER/DEVICE NAME** to select wanted devices and then **ADD**.
4. Go to step1 through step3 until finished. Press **OK** to generate new library.
5. Press **TRANSFER** to upload the library to algorithms memory in the programmer.
6. Finished. Turn on the programmer once again to work in stand-alone mode.